

C-M-L Remote Control Guide

Contact us at 312-443-8222 for more information.

TV, AUD, DVD, VCR, STB
Use one remote to control multiple devices.

SETUP
Use for programming sequences of devices controlled by the remote.

REPLAY
Skip backwards 10 seconds while watching a recording or while watching live TV.

REWIND
Rewind through parts of a recording.

PLAY
Press to watch a recording or control another device

STOP
Press to stop watching a recording or to stop a recording that is in progress.

MENU
Displays applications including the configuration menu.

GUIDE
Opens the Interactive Program Guide.

DAY +/-
Jump one day ahead or back in the Interactive Program Guide.

RED, GREEN, YELLOW, BLUE
Access additional features on your set-top box.

VOL +/-
Raise or lower the volume.

MUTE
Turn the sound off or on.

NUMBER KEYS (0-9)
Directly select a channel.

INPUT
In TV control mode, would change the input of the device you are controlling.

POWER
Turn on/off a selected device.

LIVE
Return to watching live TV.

LIST*
Displays a list of recorded shows on your PVR/DVR set-top box

SKIP FORWARD
Skip forward 30 seconds while watching a recording.

FAST FORWARD
Fast forward through parts of a recording.

RECORD
Press to record a show.

INFO
Display the current channel and program information. Press again for more detail.

PAUSE
Pause what you are currently watching.

ARROW KEYS/OK
Navigate onscreen choices.

EXIT
Exit the current screen.

PAGE +/-
Page up or down in menu screens and Interactive Program Guide.

CHANNEL +/-
Changes to the next higher or lower channel.

LAST
Recall the last channel you were watching.

ON DEMAND*
Access video on demand services.

FAV
View your favorite channels.



**If available.*

WHAT'S ON TV?

There's more than one way to see what's showing on TV.

Info Button: Press Info once for a brief description of the program you are viewing. Press Info again for more details.

OK Button: Press OK to show the "Zapper Bar." You'll see what's showing now.

Guide Button: This is the most comprehensive view of what's on. Go ahead and page through... you're bound to find something to watch.

FAVORITES

Create Favorite Lists: There are eight pre-defined favorite lists named: Favorite1, Favorite2, etc.

1. Press Menu. Arrow down to My TV and then arrow right to Edit Favorites. Press OK.
2. To select your favorites list move the right and left arrow button. Channels included in the Favorite List are marked with a ✓. Using the arrow buttons, move through the channels and press OK to add or remove a channel to your Favorite List.
3. When done, press the blue button to save your changes.

Using Favorite Lists:

1. Press FAV. By default, your list is All channels.
2. Arrow up/down to choose a Favorite List.
3. Use either the Channel Up/Down button or the Arrow buttons to move between channels in a list. Or, use the number keys to select a channel.
4. To leave Favorite mode, press FAV.

PARENTAL CONTROLS

There are two ways to use Parental Controls:

Set Program Rating Limits: To control the types of programming that can be viewed, you may set program limits based on motion-picture ratings (G, PG, R, etc.) or TV ratings (TV-G,TV-14, etc.) using the Parental Rating option in My Settings. If you attempt to tune to a channel that is airing a program with a rating at or above your rating limit, you must enter a PIN to view the program.

Set Locked Channels: You can lock entire channels via the Channel Locks option in My Settings so that they require a PIN to view programming. You may prevent locked channels from showing in the channel guide via the General Settings (locked channels would still be accessible using the number keys).